

Suresan XP2 Pole Stand For Use With 13603 1ltr Sanitiser Dispenser

Assembly guide



Contents:

1 x Pole with fixed Back Plate
complete with 2 grub screws already
fixed in position for the dispenser



2 x
Grub
Screws



1 x
Pole
with plate



Refill
OJH-13555

Instructions:

Step 1

- Remove Automated Dispenser from its box
- NOTE: Do not fill dispenser while assembling

Step 2

- Push the release button at the bottom of the dispenser to gain access to the fixing points

Step 3

- Remove the grub screws on the Pole stand
- Line up the two indicated dispenser fixing points on the image (left) to the two holes positioned on the Pole

Step 4

- Using a 4mm Hex-key to fix the dispenser using the 2 grub screws supplied

Step 5

- Fill dispenser with your required Sanitizer.
- Please note, for sanitizer gel refill, we recommend the SureSan OJH-13555, 5 Litre. We cannot take responsibility for other bulk refill products that may not be compatible with our dispensers

www.suresan.com | sales@suresan.com | 0333 006 5820

Suresan, Kites Croft Business Park, Fareham, Hampshire PO14 4LW

Suresan is a trading division of SMI Int Group Ltd. Company number: 07644080.